


wiring diagrams



- A** tandem-motor
- TK** thermal contact
- C** capacitor
- F** fuse
- K** contactor with cut-out interlock
- M** disc rotor motor
- 0** off key

- 1** on key
- external wiring
- T** transformer
- ST** limit contact
- *** if connecting remote on/off key remove the bridge
- **** wire designation